

ITEMS

(3 Press button (A) to select "Item" and press button (B) to choose an item you want your Tamagotchi to play with. NOTE: Not all characters can play with all items. SHOP

You can purchase special items or food with the Gotchi points you earn. From the "Games/Activity" menu, press button (B) to select "Shop." Scroll through the items available and press button (B) to buy an item. Purchase Up to 15 foods to keep in your Meals or

Snacks lists and a maximum of 30 items



Ð

130 0

Occasionally, the Shop Keeper will offer travel tickets to your favorite destinations. With enough Gotchi points, you can fly to places around the globe. Afterward, visit the Travel Agency @ Tamagotchi Town (www.tamatown.com) to pick up your souvenir.

in your Item list.

Did you find a secret code?

At the shop counter screen, press button (A). Then, press button (A) quickly three times. When the shop owner's face appears surprised, punch in the secret code to reveal a new item. HINT: There are seven secret codes, each revealing something different! Collect all 7 secret codes to earn a special 8th item!

PASSWORD

Use passwords to visit Tamagotchi Town (www.tamatown.com)! Play games, travel around the world, and visit your parents or the Tamagotchi King. Afterward, enter your individual password here to claim an item.

SOUVENIR

After receiving an item from one of your adventures at Tamagotchi Town, view them here.

CONNECTION/COMMUNICATION (Using IR SENSOR)

- 1. Press button (A) to select the "IR Icon." Choose the version your friend has by pressing button (A)
- and then (B) to select. 2. Choose "Game", "Present" or "Visit."
- 3. "Stand By" will appear on the screen.
- 4. Position both toys together with the IR sensors at the top facing each other.

5. Press button (B) to begin IR communication.

GAMES Play 4 randomly chosen games with your friend.

PRESENT Wrap and send a gift to your friend! See "Friend List" for more details.

VISIT Spend time with your friend and share secrets.

DEVELOPING RELATIONSHIPS

Your relationships improve and develop as you make more connections with your Tamagotchi. After several connections, you and your favorite partner may become good companions. If so, an egg will appear on each screen. Care for your new egg to raise the next generation of Tamagotchi.

03580

ASSPORT

PLAVMATE" ØVER.3 OTHERS

Sometimes your Tamagotchi can be very 11ME CU1 naughty or may just need a pat on the back! PRAISE Use button (A) to select the "Discipline Icon" and button (B) to choose either "Time Out" (when naughty) or "Praise" to cheer up your Tamagotchi.

When to discipline? • When it calls/beeps even when it's not hungry. • When it refuses food even when it is hungry.

Did you discipline your Tamagotchi well? Your Tamagotchi may send an unexpected 3 present to your friend. This could be because TIME OUT your "Training" level is not high enough. Select "Time Out" to discipline it.

Tamagotchi Connection is an interactive virtual pet that will evolve differently depending on how well you take care of it. Play games with it, cure it when it is sick and it will develop into a good companion!

Version 3 has some exciting features!

- 1. Using infra-red technology, your Tamagotchi can connect with others to make friends, play games and
- exchange gifts! Find a compatible friend and you can raise several generations of Tamagotchis. 2. Using Gotchi points, you can buy special foods and new items for your Tamagotchi. See "How to Take Care of
- Your Tamagotchi" for details. 3. AND... With a new series of passwords, you can visit Tamagotchi Town! Tamagotchi Town (www.tamatown.com)

is the virtual world where Tamagotchis live and play. There, you can play games, shop for additional items, travel to foreign destinations, visit your parents, and earn gifts to keep in your Tamagotchi Connection!

HOW TO WAKE YOUR TAMAGOTCHI

1- Pull out the tab from the side of the casing and Tomora in the side of the (\odot) after a long beep. S 2- To reset, press the Reset Button on the back

of the casing with a pointed object like a pen. NOTE: Be careful not to apply too much pressure, especially with a sharp object.

3- To set the date and time, press button (B) 1/ 1 Am 0:00 m 3:11 and the time screen will appear. Set the month, date, hour and minute by using button (A) to scroll and button (B) to choose/set the

correct number. BIRTHDAY NOTE: As some special events occur on specific dates, please set up the date carefully.

- 4- Set your birthday month/date. Tamagotchi 1/1 might celebrate your birthday!
- 5- Choose a 5 letter user name by using button USER NAME (A) to scroll through the alphabet and button LUCKY (B) to choose letters.
 - NOTE: After selecting a user name, you cannot chanae it.
- 8 6- After returning to the normal screen, you will discover if your Tamagotchi is a boy (dark) or
- e 🖸 a girl (light). 7- Choose a 5 letter name for your Tamagotchi
 - by using button (A) to scroll through the alphabet and button (B) to choose letters NOTE: After naming your Tamagotchi, you cannot change it.

When the "Skull Icon" or "Tooth Icon" appears, your Tamagotchi is sick. Use button (A) to select the "Health Icon" and button (B) to nurse it back to health. Sometimes it may take more than one dose of medicine!



NAME

LEO



FRIEND LIST

Use button (A) to select the "Friend List Icon" and button (B) to view your list of friends and presents.

FRIENDS Use button (B) to select a "Friend." Press button (B) again to check your level of friendship. Your friendship level improves with the more connections you make with other Tamagotchi, Friendship levels are shown below:



Acquaintance> Buddy> Friend> Good friend> Best friend>

If you attempt to connect with more than 50 friends. "SORRY! LIST FULL" will appear. You must delete one of your friends if you wish to add more. Press button (A) to scroll through your friends. Press button (B) to choose a friend to delete. Confirm your selection by choosing "YES."

PRESENT Before you can send a present to your friend, you must wrap it. Press button (A) to select "Present." Use button (A) and (B) to select either "Food" or an "Item." Press button (B) to select an item to send to your friend. Confirm and wrap your selection by choosing "YES." You can also unwrap the present by the same command.



THE GROWTH PROCESS Your Tamagotchi can evolve in different stages





Tamagotchi	Discipline /	/ I	1
	Medici	ne Lights	Friend List
s in a bad mood		Lights	

When Tamagotchi needs something, it calls you with a beep and the Attention icon is highlighted. Check what it MEQL needs with the Health Meter and play, feed or discipline it.

POINTS Keep track of your Gotchi points here. And, when you're ready to visit the King of Tamagotchi Town, use this menu to make a donation. After viewing your points summary, press button (B). Confirm your donation by selecting "YES." Enter several donations of at least 5,000, 12,000 or 30,000 points and press button (B). Choose "YES." The King will thank you for a donation and provide you with a password necessary to visit him at Tamagotchi



FAMILY View your Tamagotchi heritage. Press button (B) to select the "History Icon" to view your previous Tamagotchis. Select the "Parent Icon" to view your parents and grandparents. Use the password provided to visit PARENT them in Tamagotchi Town.

THE MATCHMAKER

• If your Tamagotchi grows old and hasn't found a partner, a "Matchmaker" may appear to suggest I a partner for you! Finding a life partner is necessary to raise future generations of Tamagotchi. If you are unable to find a suitable partner, your Tamagotchi will

continue to grow old until it passes away. • Once a partner is found, a new egg representing the next generation will appear. For the first 24 hours, your Tamagotchi will take care of all the needs of the new Tamagotchi unless it becomes sick. Nurse it back to health with a dose or two of medicine.

• Once the parent leaves, you'll be asked to name your new Tamagotchi. Continue to feed

l¦J⊙ | and care for it. Develop good relationships with other Tamagotchis to continue raising several generations of Tamagotchi.

IF YOUR TAMAGOTCHI PASSES AWAY



points to shop. USER NAME USER NAME LUCKY Check your user name. FOOD 5NACK

RESET OPTION

When to reset? after several minutes • When you change the battery. After pressing the RESET button, choose either will be erased (Gotchi points, items, Friends list).

HOW TO REPLACE BATTERY



4) swing toy at anyone, 5) step on toy





HOW TO TAKE CARE OF YOUR TAMAGOTCHI

🛞 (HEALTH METER

2

HAPPY COOO

TRAINING

inni

2 L B

NAME JEN

GENDER | GIRL

2480p

@

SCONE

1

Select the "Health Meter Icon" with button (A) to check the following information regarding your Tamagotchi: Level of Hunger/Happiness • Level of Training • Age • Weight • Name • Gender • Generation • Gotchi Points • User Name.

• LEVEL OF HUNGER/ HAPPINESS

The number of hearts you have indicates your pet's Hunger and Happiness (the more the better)

LEVEL OF TRAINING

The number of dots indicates your pet's level of training (the higher the better).

Every day your Tamagotchi lives, it becomes 1 year older. Keep it healthy and don't allow its weight to get too high.

GENDER/GENERATION

Check the gender of your Tamagotchi (boy or girl) and its current generation. If your Tamagotchi receives an egg on the screen, it will grow to become the next generation of your Tamagotchi

• GÓTCHI POINTS

Check how many Gotchi points you've earned by playing games. Use these Gotchi

Press button (A) to select the "Food Icon." Choose from a variety of meals or snacks. Use Gotchi points to buy additional food items and store up to 15 of your Tamagotchi's favorite meals or snacks. But, be careful to feed your Tamagotchi only when it's hungry. Overfeeding it might make it become sick or overweight

• The first time you activate your Tamagotchi. When the image/screen freezes or does not move

- "DOWNLOAD" or "RESET." If you select "DOWNLOAD", your Tamagotchi will begin from the last major event (waking up, growing, IR communication). If you select "RESET", your Tamagotchi will start over and your memory

Requires 1 CR-2032 3V battery. Using a small screwdriver, turn the screw counter clockwise to loosen. Remove back as shown, and remove the old battery. Insert the new battery as shown. NOTE: Make sure you use a new battery. NOTE: You will NOT need to change the batteries before using your Tamagotchi for the first time.

CAUTION: Keep batteries away from children. Batteries may be harmful if swallowed.

TOILET/FLUSH



When your Tamagotchi makes a mess, press button (A) to select the "Toilet Icon" and use button (B) to clean up.

GAMES/ACTIVITY

GAMES

As your Tamagotchi grows through each stage of life, the number of games to play will increase to a total of six games. Press button (A) to select the "Games Icon" and press button (B) to choose a game to play.

• GET 🔊

Catch the falling music notes and avoid the messes. Use buttons (A) and (C) to move left or right.

BUMP GAME

Bump other Tamagotchis. Press button (B) to select the scaling level of power before meeting your opponent.

FLAG GAME

Watch for the flags appearing on-screen. Using button (A) or (C), move left to right to follow the flags. Beware of the imitation flag!

HEADING GAME

Press button (A) or (C) to move your Tamagotchi left or right. Then, press button (B) to bounce the ball.

MEMORY GAME

Watch the sequence of arrows and then use the buttons to repeat back the pattern. Each round will become more difficult than the last.

• SPRINT GAME

Press any button continuously to help your Tamagotchi race to the finish line.



HOW TO SET UP TIME



• To see the current time, press button (B) while PM 2:00 nn at the main screen.

• To change the time, press button (B) to view the current time. Press and hold buttons (A) and (C) together until the date begins to flash. Use button (A) to scroll and button (B) to choose/set.

SOUND ON/OFF

Press and hold buttons (A) and (C) together. Select sound ON or OFF.

PAUSE MODE

To place Tamagotchi in PAUSE mode:

- Press and hold button (A), then press button (B). "PAUSE" will appear on screen below your Tamagotchi character. While in PAUSÉ mode, the clock will continue to run, but Tamagotchi's growth stops until taken out of pause mode.
- To take Tamagotchi out of PAUSE mode: Press and hold button (A), then press button (B). "PAUSE" will disappear from the screen and your Tamagotchi will begin to move again.

Input this PASSWORD 20689 94292 in Tamagotchi[®] Connection[™]: Corner Shop[™] for the Nintendo DS[™] and discover a surprise!

▲ CAUTION: PLEASE READ BEFORE PLAYING WITH TOY

• Do not: 1) aim toy at anyone, 2) hit anyone with toy, 3) poke anyone with toy, • Be careful not to pinch fingers with hinged parts of toy.



CAUTION: Keep batteries away from children. Batteries may be harmful if swallowed. Requires 1 CR-2032 (3V) battery. Battery included. NOTE: Do not CAULION: Keep batteries away from children. Batteries may be homman is swanowed, however, inspector of sector participation of the sector part

Conforms to safety standard ASTM F963-96a. Color, style and decoration may vary. Distributed by Bandai America Incorporated, 5551 Katella Avenue, Cypress, California 90630. TM & © 2006 Bandai. TAMAGOTCHI, TAMAGOTCHI CONNECTION and all related logos, names and distinctive likenesses thereof are the exclusive property of Bandai. © Bandai, Wiz 2004-2006. All rights reserved.