




bandai.com



Ages 8 and up. Asst. #26000



SPECIAL PASSWORD 04932 64130
Go to www.tamagotchiconnection.com to find more information!

1 Tamagotchi® Connection® is an interactive virtual pet that will evolve differently depending on how well you take care of it. Play games with it, feed it food and cure it when it is sick and it will develop into a good companion! V5 has some exciting features!


- For the first time ever, you can now raise multiple Tamagotchi characters in one Tamagotchi toy! And, with a wider display, you can view all the Tamagotchi brothers and sisters on-screen as you take care of them.
- Using Gotchi points, you can buy special foods and new items for your Tamagotchi family.
- With a series of passwords, you can visit the Tamagotchi EXPO (www.tamatown.com), a new virtual world where Tamagotchis are holding a worldwide fair, and visit pavilions from countries around the world! *NOTE: The V5 toy is only compatible with the V5 website.*

4. An opportunity to strengthen the family bond of your Tama-family and to create new Tamagotchi characters you haven't met yet.


What will your Tamagotchi family grow up to become under your care and guidance?

HOW TO WAKE YOUR TAMAGOTCHI

- Pull out the tab from the side of the casing and Tamagotchi will appear after a long beep.
- To reset, press the Reset Button on the back of the casing with a pointed object like a pen. *NOTE: Be careful not to apply too much pressure, especially with a sharp object.*
- To set the date and time, press button (B) and the time screen will appear. Set the month, date, hour and minute by using button (A) to scroll and button (B) to choose/set the correct number. *NOTE: As some special events occur on specific dates, please set up the date carefully.*
- Set your birthday month/date. Tamagotchi might celebrate your birthday.
- After returning to the normal screen, you will discover 3 eggs. Each egg will produce Tamagotchi brothers and sisters!
- Choose a 5 letter name for your Tamagotchi family by using Button (A) to scroll through the alphabet and button (B) to choose. *NOTE: After naming your Tamagotchi family, you cannot change it.*




HOW TO MAKE YOUR TAMAGOTCHI GROW



When your Tamagotchi family needs something, it calls you with a beep and the Attention or Training icon will be highlighted. Check what it needs with the Health Meter and play, feed or train it.


HOW TO TAKE CARE OF YOUR TAMAGOTCHI

- HEALTH METER**
Select the "Health Meter Icon" with button (A) to check the following information regarding your Tamagotchi:
• Level of Hunger/Happiness • Level of Bond Percentage
• Family Type • Family Name • Generation • Gotchi Points • Family Information
- LEVEL OF HUNGER/HAPPINESS**
The number of hearts you have indicates your Tamagotchi family's Hunger and Happiness (the more the better).
- LEVEL OF BOND PERCENTAGE**
The percentage indicates how strong the bond of your family is (MAX 100%).



THE GROWTH PROCESS

Your Tamagotchis can evolve in different stages depending on how you care for them.



- TYPE OF FAMILY**
The type of family you have is listed on the lower portion of the screen. This type of family is determined by the characters you are raising.
- FAMILY NAME/GENERATION/GOTCHI POINTS**
Check your Tamagotchi's family name. You can also confirm its current generation. If your Tamagotchi receives eggs on the screen, they will grow to become the next generation of your Tamagotchi. You can also view how many Gotchi points you've earned by playing games. Use these Gotchi points to shop.
- CHARACTER TYPE /FAMILY ROLE/GENDER**
View the types of characters in your Tamagotchi family. You can also see what role each family member plays in the lower half of the screen. You can also see if your characters are boys or girls on the same screen.


- FOOD**
Press button (A) to select the Food Icon. Choose from a variety of meals or snacks. Use Gotchi points to buy additional food items. With the new V5, you can also get new food items from all over the world and eat them over and over again. But, be careful to feed your Tamagotchi only when it's hungry. Overfeeding it might make it become sick or overweight.
- TOILET/FLUSH**
When your Tamagotchis make a mess, press button (A) to select the "Toilet Icon" and use button (B) to clean up.
- GAMES**
As your Tamagotchis grow through each stage of life, the number of games to play will increase to a total of four games. Press button (A) to select the "Games Icon" and press button (B) to choose a game to play.

- TV SURFING GAME**
Watch the picture on the upper right screen and match the picture on the TV screen. Press button (A) to match the pictures at the right time.
- TEA TIME GAME**
Check the cups on the table. If they are placed correctly, pour the tea. If not, don't pour, but pass. Press button (A) to pour tea on the right and press button (B) to pour tea on the left. Press both buttons (A) and (B) together to pour the tea on both sides.

- GOLF PUTT GAME (With Father)**
Make a putt by adjusting the power of the swing. Watch the power meter and stop it at the appropriate time to make a strong swing. Press button (A) to stop the meter and to determine the strength of the swing.
- SHOES PAIRS GAMES (With Mother)**
A mother on the left will choose a shoe. Find the matching shoe to make a pair. Press button (A) to choose a shoe from the selection at the bottom of the screen.

CONNECTION/COMMUNICATION
Select the IR Icon with button (A) to do the following with your Tamagotchi: V5 connection • Special • P C

- V5 CONNECTION**
Connect with another Tamagotchi V5 owner using the IR Sensor. *Note: The V5 toy can connect only with another V5 toy. It cannot connect with previous versions of Tamagotchi.*
- 1- Choose "Game" or "Marry".
- 2- "Stand By" will appear on the screen.
- 3- Position both toys together with the IR sensors facing each other (See illustration).
- 4- Press button (B) to begin IR communication.



- GAME** - Play 2 randomly chosen games with your friend.
- MARRY** - Marry two V5 adult characters. Choose "MARRY" and you will be presented with 2 choices, "GIVE" and "ACCEPT". Each player must choose either one of the choices. The character from the toy that chooses "GIVE" will "jump" to the toy that chooses "ACCEPT", indicating that it is giving itself as a partner to marriage. After marrying, it will begin a new generation of a Tamagotchi family. *NOTE: Make sure you're connecting with a good friend or the Tamagotchis may refuse to marry one another. If this happens, you can strengthen their relationship by playing more games together through the IR connection.*

- SPECIAL**
When you choose "SPECIAL", you will be prompted to enter a PASSWORD. You can collect SPECIAL PASSWORDS at www.tamatown.com to collect unique items or to get discounts for your purchases. *NOTE: A SPECIAL PASSWORD is already hidden in these instructions. Can you find it? And a SPECIAL PASSWORD sometimes has a couple of effects. Let's enter PASSWORDS again and again!*

PC
Use this function to visit the Tamagotchi EXPO V5 website (www.tamatown.com). To enter the Tamagotchi EXPO, you will need the 14-digit LOGIN number available on-screen. *NOTE: To avoid losing the saved data in your V5 toy, do not press any buttons while viewing your 14-digit password; your toy will remain PAUSED during your visit to the Tamagotchi EXPO.*
After visiting the Tamagotchi EXPO, you will be provided with a new 14-digit LOG OUT number. Press button (A) to bypass your LOG IN number and to enter the new LOG OUT number. Use button (A) to scroll through the digits and button (B) to select. You may use button (C) to erase.

WHAT'S NEW ABOUT THE V5 WEBSITE?
In the V5 website, you can visit the TAMA & EARTH EXPO!! Tamagotchis living on TAMA PLANET began the TAMA & EARTH EXPO to learn more about EARTH and its different regions. At the EXPO, Tamagotchis get to experience everything fun about different countries on EARTH, including fun places to visit, delicious foods to eat, and the many customs of each country. (Of course, it may look a little different and humorous from what you know since it was built from a Tamagotchi's point of view!)
At the TAMA EXPO, you can visit pavilions from the U.S., Europe, Japan, Asia and all over the world. When visiting each pavilion, you can enjoy all kinds of games and collect souvenirs from around the world. You'll get to see firsthand how Tamagotchis experience our cultures and languages. Enjoy exploring the TAMA EXPO!!

- TRAINING**
Sometimes your Tamagotchis will call you when they want to play. It's your chance to train them! Use button (A) to select the "Training Icon". Choose an item to play with from the 3 choices available by using button (B).



WHY DO YOU NEED TO TRAIN TAMAGOTCHIS?
Tamagotchis strengthen their family bond by playing together. And, the type of toys you give them will also influence the type of characters they will become! For example, when you give them blocks, they tend to be more intellectual. If you give them tambourines, they tend to be cheerful. With crayons, they tend to be soothed and more easygoing. Make sure you spend enough time training your family to create new and different characters!

- ITEM BOX**
The Item Box will keep and store tools and items that you will need to care for your Tamagotchis. It contains 4 categories.

- MEDICINE**
When the "Skull Icon" or "Tooth Icon" appears, your Tamagotchis are sick. Use button (A) to select the "ITEM BOX ICON" and button (B) to select. Select "MEDICINE" to nurse them back to health. Sometimes it may take more than one dose!
- ITEM**
"ITEM" contains the items you have purchased or collected at the website. To use an item, select it with button (A) and then button (B). Tamagotchis love to play with many different items! *NOTE: Not all the characters can play with all the items.*

- SOUVENIR**
"SOUVENIR" contains souvenirs from around the world that you have collected through TV shopping or at the TAMA EXPO. Collect them all!

- RARE**
"RARE" contains special items that you can't easily find. You might be able to meet a unique Tamagotchi by using some of these items. If you get a "RARE" item, make sure to use it right away to discover what it does! *NOTE: In V5, using an item does not mean losing it. You can keep items after you play with them*

- TV**
"TV Icon" is a new icon for V5. It has 3 channels. At each of these channels, you can enjoy 3 different activities, including TV shopping, dating and traveling.

- TV SHOPPING**
Press button (A) to choose "TV Icon" and button (B) to select. Then select "TV SHOPPING" with button (B) to shop for items on TV.




You can choose items on the screen by using button (A) to scroll and button (B) to select. Different items will be available each time you watch. *NOTE: In V5, there are no limits to the number of items you can own. You may purchase as many items as you want with your Gotchi points.*

- DATING SHOW**
Press button (A) to choose "TV Icon" and use button (B) to select. Then select "DATING SHOW" with button (B) to try the dating show.
First, choose the character from your Tamagotchi family for which you would like to find a partner. Otokitchi the Matchmaker will then appear and introduce a partner for it. If you agree with her suggestion, select "MARRY" with button (B) and the Tamagotchis will marry.

NOTE: You can only select "DATING SHOW" if your characters have become adults and reached a marrying age. Otokitchi will introduce a variety of Tamagotchis. You can try "DATING SHOW" up to 3 times a day to try to find a perfect partner.


- TRAVEL SHOW**
Press button (A) to choose "TV Icon" and use button (B) to select. Then select "TRAVEL SHOW" with button (B) to travel to your favorite destinations.



While traveling, your Tamagotchi's growth stops until they return from traveling. You will not need to care for them while they are traveling. Press button (C) to return from travel. *NOTE: Using "TRAVEL SHOW" acts as the same function of PAUSE MODE from previous versions.*

- FRIEND LIST**
Use button (A) to select the "Friend" List Icon and button (B) to view your list of friends and family history.

- FRIENDS**
Use button (B) to select a "Friend." Press button (B) again to check your level of friendship. Your friendship level improves with the more connections you make with other Tamagotchis. Friendship levels are shown below:



- MEMORY**
View your Tamagotchi family history. Press button (B) to select the "Memory" to view your previous Tamagotchis that are no longer under your care.

- AFTER MARRIAGE**
Once you find a partner for one of your adult Tamagotchis (either by IR connection or by "DATING SHOW"), your remaining characters will return to TAMA PLANET. The 2 married characters will soon become parents and they will produce new eggs!
The next generation of Tamagotchis will be born.

- IF YOUR TAMAGOTCHIS HAVE GONE.....**
If you don't take proper care of your Tamagotchis, sometimes they can get angry and decide to return to their home on TAMA PLANET.

- A NEW FEATURE FOR BUTTON (C)**
Pressing button (C) at the main screen will show you a variety of actions for your family! These actions will vary depending on your bond percentage. Getting a higher bond percentage can create extra actions!

- ABOUT FAMILY TYPES**
In V5, depending on how you care for your family, it might become somewhat eccentric. These types of families are the NINJA FAMILY, LARGE FAMILY or PETITE FAMILY. These families can appear if you don't care for your Tamagotchis well. Some examples of poor care include ignoring them, feeding them too much, or not feeding them enough.


- RESET OPTION**
When to reset?
• The first time you activate your Tamagotchi.
• When the image/screen freezes or does not move after several minutes.
• When you change the battery. After pressing the RESET button, choose either "DOWNLOAD" or "RESET." If you select "DOWNLOAD", your Tamagotchi will begin from the last major event (waking up, growing, IR communication). If you select "RESET", your Tamagotchi will start over and your memory will be erased (Gotchi points, Items, Friend list).

- HOW TO SET UP TIME**
• To see the current time, press button (B) while at the main screen.
• To change the time, press button (B) to view the current time. Press and hold buttons (A) and (C) together until the date begins to flash. Use button (A) to scroll and button (B) to choose/set.

- SOUND ON/OFF**
Press and hold buttons (A) and (C) together. Select sound ON or OFF.

- HOW TO ADJUST CONTRAST**
Press and hold buttons (B) and (C) together. Select contrast level to press button (A) and (B).

- HOW TO REPLACE BATTERY**
Requires 1 CR-2032 3V battery. Using a small screwdriver, turn the screw counter clockwise to loosen. Remove back as shown, and remove the old battery. Insert the new battery as shown. *NOTE: Make sure you use a new battery. NOTE: You will NOT need to change the batteries before using your Tamagotchi for the first time.*



CAUTION: PLEASE READ BEFORE PLAYING WITH TOY
• Do not: 1) hit anyone with toy, 2) poke anyone with toy, 3) swing toy at anyone, 4) step on toy.

WARNING: CHOKING HAZARD - Small parts. Not for Children under 3 years.

CAUTION: Keep batteries away from children. Batteries may be harmful if swallowed. Requires 1 CR-2032 (3V) battery. Battery included. **NOTE:** Do not mix old and new batteries. Do not mix alkaline, standard (carbon-zinc) or rechargeable (nickel-cadmium) batteries. Dispose of used batteries properly.

Conforms to safety standard ASTM F963. Color, style and decoration may vary. Distributed by Bandai America Incorporated, 5551 Katella Avenue, Cypress, California 90630. TM & © 2007 Bandai. TAMAGOTCHI, TAMAGOTCHI CONNECTION and all related logos, names and distinctive likenesses thereof are the exclusive property of Bandai. © Bandai, WIZ 2004-2007. All rights reserved.